



A Product Development Company

GOPHER WIRE: Technical Information for Perimeter Protection Installations

Gopher wire is specifically designed for gopher exclusion. The hexagonal woven mesh measures 3/4" across the flats of the hexagon and are small enough to keep young gophers out (a size determined by a young gopher's shoulder girth at the weaned age of about 8 weeks). The 20 gauge wire stands are thick enough to resist potential gopher chew through. Root Guard Gopher wire rolls are "double galvanized"—first the wire strand is electro-plate galvanized, then its woven into the mesh and finished with a second "hot-dipped galvanizing after weaving". This double galvanizing prevents rust and deterioration of the steel when the wire is buried.

Vertical Barrier General Information:

Most gopher activity is near the surface so a vertical barrier 24" deep with a 6" horizontal flat extending outward at the bottom of the trench and 6" extending above grade will provide good gopher resistance. We've had many customers install this type of vertical barrier with great success.

Tools needed:

- 6" wide Trenching Shovel or mechanical Trencher
- Tape Measure
- Stakes and string or marking paint
- Underground utility marker (rent tool or hire job out)
- Root Guard Gopher Wire Roll(s)
- Wire cutters
- Landscape staples
- Hammer



Walk Behind Selfpropelled Trencher, PTO Trencher Attachment & Trenching Shovel



How to determine how much wire you'll need for the job:

We recommend our 36" wide x 100' long Root Guard Gopher Wire Rolls.

Add the length of all the sides of the area to be protected and divide by 100 to arrive at the quantity of rolls you'll need for the job. Any partial roll needed, round up using the following guidelines: If the excess is less than .25 buy our 36" x 25' roll, and if greater than .25 buy another 100' roll.

Preparation:

Mark all underground utilities

Mark out perimeter

Runs need to be straight and the bottom smooth and even to prevent buckling of the wire mesh.

Installation:

- Dig trench 24" deep and 6" wide
- Roll wire out on the ground next to the trench
- At the end of each run cut the length at the outside edges of the trench.
- Then cut a horizontal 6" long slit in the wire mesh 6" from the bottom of the wire so you can form an overlap at the corner (see Figures 1, 2 and 3)
- Insert the wire vertically in the trench forming the outward facing flap at the bottom
- Fold the wire over at each corner
- Using landscape staples stake the wire in place as needed
- Repeat for each run
- Once all runs are installed stake corner seams securely in place
- Fill and compact trenches

Maintenance:

- Weekly walk perimeter look for any gopher activity inside and outside the barrier. Any activity should be stopped.
- Remove any foliage crossing over the barrier
- Straighten up any area where the above ground wire is bent
- Periodically plow or rotor-till the area adjacent to the barrier. Outside the barrier is preferred, but if not accessible then inside is ok. Disturbing the soil next to the barrier prevents plant growth(food source for gophers), and destroys burrows and tunnels.

Important safety note:

- Anytime trenching know where and if there are any underground utilities before digging.




Figure 1: Gopher Wire laid out over a run of the trench, Top View




Figure 2: Vertical Barrier Trench Cross-section at Corner




Figure 3: Vertical Barrier Trench Top View Corner, Gopher Wire installed and overlapped

Please contact us with any questions or concerns pertaining to the use of Digger's Root Guard Gopher Wire.

Mail:

PO Box 1551

Soquel, CA 95073

Distribution Center:

2825 Mattison LN

Santa Cruz, CA 95065

Phone: 831-462-6095

Fax: 831-464-1825

Web: www.gopherbasket.com

e-mail: diggerco@att.net